



Návod na sestavení a používání motorky Racing sport 6V, pro nejmenší,



⚠ WARNING!

This toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties
Not to be used in traffic
This toy has no brake
CHOKING HAZARD - Small parts. Not suitable for children under 36 months



⚠ WARNING!
TO AVOID INJURY
BABIES AND CHILDREN
BAG IMMEDIATELY

WARNING!

This toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties
Not to be used in traffic
This toy has no brake

CHOKING HAZARD - Small parts. Not suitable for children under 36 months



WARNING!
TO AVOID INJURY TO
BABES AND CHILDREN
DO NOT REMOVE THE
BAG GAGGERS



⚠ WARNING!
This toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties. Not to be used in traffic. This toy has no brake.
CHOKING HAZARD - Small parts. Not suitable for children under 36 months.
CE










WARNING!
Do not play with this toy in the street or on roads.
Do not use the toy on rough or uneven surfaces.
Do not use the toy on wet surfaces.
Do not use the toy on steep slopes.
Do not use the toy on uneven surfaces.
Do not use the toy on rough or uneven surfaces.
Do not use the toy on wet surfaces.
Do not use the toy on steep slopes.
Do not use the toy on uneven surfaces.




Poloha šroubku pro otevření sedačky,

Tepelná, samoresetovací pojistka,



NOTICE : First use, open the main compartment of battery and plug the red wire power connector to the red battery terminal

DEJSA ANKOVANÁ
CE
DOPISNENÍ



Propojení konektorů baterie a motoru,

Sport

MADE IN CHINA
100% POLYURETHANE
100% POLYURETHANE
100% POLYURETHANE









Předek,



RACING

TEMA

TEMA

BAG IMMEDIATELY!
ENFANTS ET ENFANTS, DÉPOSEZ CE SAC
TO AVOID SUFFOCATION AND DANGER TO







Vložte 2 mikrotužkové baterie R3, AAA,
pozor na správnou polaritu + a - !!,



BAG IMMEDIATELY
SERIES AND CHILDREN
LIVING









Gumové kloboučky doporučujeme přilepit lepidlem, nebo je vůbec nenasazovat, nejsou nutné,

Nabíjení baterie,

čas nabíjení 8 - 10 hod / max.15hod !!,

při nabíjení může být nabíječka i baterie teplá - toto je normální,

Nabíječka,

Při nabíjení musí být spojen !!:

bílý konektor od nabíječky s modrým konektorem INPUT,

NOTICE: First use open the protecting cap
battery and plug the red wire, over connecto
to the terminal

Červený konektor zůstane při nabíjení volný,

Sport

Důležité upozornění !,
pokud vozítko nepoužíváte, baterii nabíjejte 1x měsíčně cca 6 hodin!,
nedodržením zničíte nebo zkrátíte životnost baterie!, baterii chraňte před mrazem!,

Nabíjení baterie,

NOTICE
Do not plug the red wire into the red wire terminal. For use connect the red wire into the black wire terminal.

DĚTSKÁ AKU VOZITKA
CE







Poloha šroubku pro otevření a nasazení sedačky,



Poloha šroubku pro uzamčení sedačky,



Přejeme krásné zážitky na nové minimotorce Racing sport.